

SPEEDLITE MR-14EX II		
Power		
	Guide No. (ISO100).meters	14
Zoom		
	Zoom head	No
	focal length coverage	-
	Coverage with wide panel	-
	Auto zoom for sensor size	-
Flash modes		
	Auto exposure control	E-TTLII/E-TTL/TTL
	High speed sync (FP)	Yes
	Manual / output settings	Yes - 1/1- 1/128
	Manual steps	1/3 step
	Strobe / output settings	-
	Frequency	-
	Video light	-
	Video light power	-
	Video light colour temperature	-
Flash-related function		
	FE lock	Yes
	Flash exposure compensation	Yes
	Flash Exposure bracketing	Yes
	Second-curtain flash sync	Yes
	Modelling flash	Yes
	Colour temperature info communication	Yes
Wireless flash		
	Transmitter	Yes
	Transmission type	Infra-red
	Transmitter Max range approx	Indoors: 5m Outdoors: 3m
	Slave	No
	No of groups	3*1
	No of channels	4
	Remote Shutter Release	-
Flash head movement		
	Up	-
	Down	-
	Left	-
	Right	-
AF Assist		
	AF-assist beam	No (Focusing lamp)
	Number of AF points supported	-
	AF-assist beam type	-
Power source		
	Battery	4 x AA batteries
	Minimum recycling time *2	Approx. 5.5sec
	External power supply	Yes - CP-E4
Construction		
	Dust and water resistance	No
	Mounting foot material	Metal
Misc.		
	Custom function	12 (27 options) + 3 personal functions
	Flash settings from camera menus *3	Yes
	External flash exposure sensor	No
	PC terminal	No
	Compatible Accessories	Macro Lite Adapter 72c, 67 Compact battery Pack CP-E4 EX Series Speedlite with Slave function
	Dedicated flash bracket	No
Dimensions & weight		
	Size (W x H x D), mm	Control unit 69.6 x 118.8 x 71.4 Flash unit 129.6 x 112.1 x 25.3
	Weight (Excluding batteries), grams	455
*1 As default only flash in group C are triggered wireless, set C.Fn 5-1 to wirelessly trigger groups A & B		
*2 time taken to recharge flash after full discharge using Alkaline AA batteries		
*3 With compatible cameras only		